HARLSAN

TOP SEAL PLATE ASSEMBLY



Ensure you're getting a complete seal on your top seal plate with correct assembly.

Step	Action	Key Points
1	Have seals & brass grease distribution ring	Use our installation tool to make the job easy
2	Place first seal with red ring facing up	You will not get a seal if the ring is facing down
3	Hammer into place with installation tool	Ensure first seal is all the way in
4	Place brass grease distribution ring	This should just slide in
5	Place second seal with red ring facing up	You will not get a seal if the ring is facing down
6	Use tool & hammer to firmly seat the seal	















PARTS USED

Туре	Part Number
Installation Tool	SW10344
Seals	See https://www.harlsan.com.au/seal-plate-seals-circlip-o-ring-seal-identification-table/



PERTH OFFICE

59 Edward St, Osborne Park Western Australia 6017 Telephone: +61 8 9201 9040



KALGOORLIE OFFICE

37 Kakarra Rd, Kalgoorlie Western Australia 6430 Telephone: +61 8 9021 1288